



Popup Food Container Set Medium

~~\$28.95~~ **\$22.90**

Details

Keep your leftover food fresh for the next day with the Medium Food Container Set. These collapsible and space-saving containers are perfect for caravanning, camping or just around the house.

Each container is made of food grade silicone and will collapse down when not in use for easy storage. The BPA free lid locks on, and the smaller containers nest inside the larger ones which will save you some room when space is limited.





And you can re-heat last night's dinner or throw this container in the wash as they're microwave and dishwasher safe for easy use. Transport your food and keep it fresh with the Medium Food Container Set.

Collapses when not in use
Space saving
Smaller containers nest inside larger containers
Food grade silicone container
BPA free clip lock lid
Unlock lid before use in microwave
Dishwasher and microwave safe

Specifications

Snowys Code:	140176
Supplier Code:	COMP785MXM
External Dimensions:	19.5L x 19.5W x 9.3H cm 25L x 25W x 8.5H cm
Packed Dimensions:	19.5L x 19.5W x 3.5H cm 25L x 25W x 3.5H cm
Capacity:	1.4 L 3.1 L
Material:	Polypropylene Food Grade Silicone
Weight:	0.24 Kg 0.36 Kg
Warranty:	1 Year

Have a question about this product?

 1300 914 007  service@snowys.com.au  Snowys Outdoors  Snowys Outdoors

Changed your mind?

For all information on how to return an item, visit www.snowys.com.au/returns